



Tenda V12 - FTTN

WiFi Router Setup Guide

Please don't throw me away




skymesh.net.au

How to connect

Setting up your new router

Skymesh routers arrive pre-configured. Simply plug in the supplied cables as per the diagram, switch on the new router and connect to it using the supplied WiFi password.

Note: This cabling setup is essential for an active connection. Please avoid changing the cabling setup below to prevent disconnection.



Tenda V12

Please plug into the
grey DSL port

Warranty

Your new router comes with a 3-year advanced replacement warranty for full peace of mind. More information on our warranty can be found at skymesh.net.au/warranty

How to restart your internet connection

If you're offline, please follow the steps below as they may resolve any potential faults. If issues persist, please call us on **1300 759 637**.

- 1 First, turn off your wireless router.
- 2 Wait for about **10 minutes**.
- 3 Turn your wireless router back on.

Note: Please refer to the cabling setup provided on the 'How to Connect' page. This cabling setup is essential for an active connection.

Need some help?

If things don't go to plan and you require assistance, please contact our friendly Brisbane-based team.

Contact us on **1300 759 637** or via LiveChat at skymesh.net.au.

We're open:

8am - 7pm Monday to Friday
9am - 5pm Weekends
9am - 5pm Public Holidays
Australian Eastern Standard Time (AEST)